R82 Meerkat rocker with handle

Code (s) : 0500-118598-1, 0500-117047-1

Allows the child to effortlessly rock forward and backward. It can be easily mounted under the base plate, even when a child is standing within the frame.



FEATURES

- Suitable for use with the Meerkat standing aid